

SHARP

MODEL:

IB-SD23Y-N

IB-SD23Y-P

IB-SD23Y-W

Hair Dryer


Instruction Manual



PT. SHARP TRADING INDONESIA
Jl. Swadaya IV Gedung Lama Lot No.7
Kel. Rawaterate – Kec. Cakung, Jakarta Timur.
DKI Jakarta Raya, 13920

I.30.ST11.00301.0513

Please read these instructions completely before operating the unit



Instruction Manual

1. Important

Read this user manual carefully before you use the appliance and keep it for future reference.

WARNING: Do not use this appliance near water.

- When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a risk, even when the appliance is switched off.
- **WARNING:** Do not use this appliance near bathtubs, showers, basins or other vessels containing water.
- Never block the air grilles.
- Do not insert metal objects into the air grilles to avoid electric shock.
- Before you connect the appliance, ensure that the voltage indicated on the appliance corresponds to the local power voltage.
- Do not use the appliance for any other purpose than described in this manual.
- Do not use the appliance on artificial hair.
- When the appliance is connected to the power, never leave it unattended.
- Always unplug the appliance after use.
- Never use any accessories or parts from other manufacturers or that Sharp does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.
- Do not wind the mains cord round the appliance.
- If the mains cord is damaged, you must have it replaced by Sharp, a service centre authorised by Sharp or similarly qualified persons in order to void a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the appliance overheats, it switches off automatically. Unplug the appliance and let it cool down for a few minutes. Before you switch the appliance on again, check the grilles to make sure they are not blocked by fluff, hair, etc.

Environment

Do not throw away the appliance with the normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you help to preserve the environment.

2. Dry your hair

1. Connect the plug to a power supply socket.
- For precise drying, attach the concentrator (5) onto the hairdryer (6).
- To disconnect the attachment, pull it off the hairdryer.

2. Adding Fragrance
 - Open the fragrance bracket (4) on the top of the hair dryer.
 - Take a cotton swab and drip desired perfume onto it. Then, put the cotton in the gap of the fragrance bracket.
 - Put back the fragrance bracket back to its original place.

3. Adjust the temperature switch (2) and airflow switch (1) to suitable Positions

Switch	Setting	Function
Temperature	Quick Dry	Dry shower-wet hair quickly
	Thermo protect	Gently dry the hair at a constant temperature
	Cool Care	Dry the hair with care and seal in shine
Airflow	Strong airflow and fast drying	
	Gentle airflow and styling	
	Switch off	

After use:

- a. Switch off the appliance and unplug it.
- b. Place it on a heat-resistant surface until it cools down.
- c. Clean the appliance by damp cloth.
- d. Fold the appliance.
- e. Keep it in a safe and dry place, free of dust. You can also hang it with the hanging loop (3).

3. Troubleshooting

Problem	Cause	Solution
The appliance does not work at all.	The power socket to which the appliance has been connected may not live.	Ensure the socket is live.
	The appliance may have overheated and switched itself off.	Unplug the appliance and let it cool down for a few minutes. Before you switch on the appliance again, check the grilles to make sure they are not blocked by fluff, hair, etc.
	The appliance may not be suitable for the voltage to which it has been connected.	Ensure that the voltage indicated on the type plate of the appliance corresponds to the local power voltage.

SHARP

MODEL:

IB-SD23Y-N

IB-SD23Y-P

IB-SD23Y-W

Hair Dryer


Buku Manual



PT. SHARP TRADING INDONESIA
Jl. Swadaya IV Gedung Lama Lot No.7
Kel. Rawaterate – Kec. Cakung, Jakarta Timur.
DKI Jakarta Raya, 13920

I.30.ST11.00301.0513

Silakan baca instruksi secara menyeluruh sebelum mengoperasikan unit



Buku Manual

1. Penting

Bacalah petunjuk pengguna ini secara seksama sebelum Anda menggunakan alat ini dan simpan untuk referensi di masa mendatang. PERINGATAN : Jangan menggunakan alat ini dekat air.

- Bila alat digunakan di kamar mandi, cabutlah stekernya setelah digunakan karena air dapat menimbulkan risiko, sekalipun alat tersebut dimatikan.
- PERINGATAN: Jangan menggunakan alat ini di bak mandi, pancuran, bak atau tempat berisi air lainnya.
- Jangan menutup kisi-kisi udara.
- Jangan memasukkan benda logam ke dalam kisi-kisi udara untuk menghindari sengatan listrik.
- Sebelum Anda menghubungkan alat, pastikan voltase yang ditunjukkan pada alat sesuai dengan voltase listrik lokal.
- Jangan gunakan alat untuk tujuan lain selain yang dijelaskan dalam manual ini.
- Jangan gunakan alat pada rambut buatan.
- Bila alat telah terhubung ke listrik, jangan pernah meninggalkannya tanpa pengawasan.
- Selalu cabut alat setelah digunakan.
- Jangan gunakan aksesoris atau suku cadang dari perusahaan lain atau yang tidak secara khusus direkomendasikan oleh Sharp. Jika Anda menggunakan aksesoris atau suku cadang yang tidak direkomendasikan oleh Sharp, garansi Anda menjadi batal.
- Jangan melilitkan kabel listrik pada alat.
- Jika kabel listrik rusak maka harus diganti oleh pusat layanan resmi Sharp untuk menghindari bahaya.
- Alat ini tidak dimaksudkan untuk digunakan oleh orang (termasuk anak-anak) yang memiliki kekurangan fisik, indera atau mental, atau kurangnya pengalaman dan pengetahuan, kecuali jika mereka telah diberikan pengawasan atau instruksi yang berkaitan dengan penggunaan alat oleh orang bertanggung jawab atas keselamatan mereka.
- Anak-anak harus diawasi untuk memastikan bahwa mereka tidak bermain dengan alat ini.
- Jika terlalu panas, alat akan mati secara otomatis. Cabut alat dan biarkan dingin selama beberapa menit. Sebelum Anda memakainya lagi, periksa kisi-kisi untuk memastikan mereka tidak tersumbat bulu, rambut, dll.

Lingkungan







Jangan membuang alat ini di pembuangan rumah tangga pada saat alat tidak bisa di gunakan lagi, tapi buanglah di tempat pembuangan resmi untuk di daur ulang. Dengan melakukan hal ini, Anda ikut membantu melestarikan lingkungan.

2. Keringkan Rambutmu

1. Hubungkan steker ke stop kontak listrik.

- Untuk pengeringan yang akurat, pasang konsentrator (5) ke pengering rambut (6).

- Untuk mematikan pengering rambut, cabut steker dari stop kontak listrik.
- 2. Menambahkan Pewangi
- Buka celah penyimpanan pewangi rambut yang terdapat (4) di atas pengering rambut.
- Ambil kapas dan teteskan pewangi untuk rambut. Kemudian taruh kapas tersebut pada celah pengharum rambut.
- Masukkan kembali celah penyimpanan pewangi rambut ke tempat semula
- 3. Atur sakalar pengaturan suhu (2), Aliran Angin (1) sesuai dengan keinginan atau kenyamanan anda.

Peralihan	Pengaturan	Fungsi
Suhu	 Quick Dry	Mempercepat pengeringan rambut basah
	 Thermo protect	Mengeringkan rambut dengan suhu konstan
	 Cool Care	Mengeringkan rambut dengan menjaga dan menyinarakan rambut
Aliran Angin		Aliran udara kencang dan cepat kering
		Aliran udara yang lembut
		Mematikan

Setelah menggunakan:

- a. Matikan alat dan cabut
- b. Tempatkan di permukaan yang tahan panas sampai suhu normal.
- c. Bersihkan alat dengan kain lembab.
- d. Lipat alat.
- e. Simpan di tempat yang aman dan kering serta bebas debu. Anda juga dapat menggantung dengan loop menggantung (3).

3. Pemecahan Masalah

Masalah	Penyebab	Solusi
Alat tidak bekerja sama sekali	Soket listrik yang telah terhubung mungkin tidak hidup.	Pastikan soket dialiri listrik.
	Alat mungkin terlalu panas dan mati sendiri.	Cabut alat dan biarkan dingin selama beberapa menit. Sebelum Anda beralih kembali alat ini, periksa kisi-kisi untuk membuat yakin mereka tidak terhalang kotoran, rambut, dll.
	Alat yang dimiliki mungkin tidak cocok dengan tegangan yang telah terhubung.	Pastikan bahwa tegangan sesuai dengan voltase listrik di tempat.